

## **FITTING INSTRUCTIONS**

- 1. From back of unit mark top reinforced bracket.
- 2. Drill 6mm through top bracket
- 3. Set unit at desired height
- 4. Support unit at desired height and mark top and bottom fixing positions through drilled holes.
- 5. Drill all holes for suitable fixings.
- 6. Screw basin stud into lower fixing plug.

- 7. Loosely fix unit onto bottom fixings. **Fig 1**
- 8. Loosely fit top fixings including cover cap.
- 9. Set unit straight using a spirit level.
- 10. Tighten all fixings enough to secure the unit.
- 11. Fix waste pipes through a conventional trap. **Fig 5**
- 12. Seal all edges and joints between units with standard silicone. **Fig 3**

## RECOMMENDED FIXINGS

## Supplied by others

**Fig 2.** Top Fixing Suitable wall plug, screw and cap

**Fig 4.** Bottom Fixing Suitable wall plug, 6mm basin bracket.

## SANQUIP 3 STALL WALL URINAL











01723 512224

Fig. 1

Fig. 2

Fig. 3

Fig. 4

Fig. 5





